OPERATING MANUAL LOOP POWERED TRANSMITTER LPT-4511

MISTURA

Specification

Mounting: Sensor Mounting.

Supply: 24 V DC Input: PT-100/3W.

Range: Selectable:0-100°C,0-150°C,0-200°C,0-300°C,0-400°C

Working


- 4-20mA output is available on the supply terminal according to the signal coming from PT-100 Sensor.
- When power is turned on, RED LED turns ON.
- Select the Range as Per requirement.
- Do all Connection as shown in Connection in Connection diagram and turn on the instrument

Range selection

- To Select The Range of 0 TO 100°C, Short First pair of connector using shorting link
- To Select The Range of 0 To 150°C, Short 2nd pair of connector using shorting link.
- Similarly for 0 To 200°C, or 0 To 300°C Short 3rd or 4th pair of connector respectively.
- When all connectors are left open Range of 0 To 400°C will be Selected.

NOTE: After Changing the Range you need to Calibrate the instrument.

0To 100°C	• 0 0 0
0 To150°C	○ ● ○ ○○ ● ○ ○
0To 200°C	0000
0 To 300°C	0000
0To 400°C	000



Above picture shows the range of 0 to 100°C

Wiring Diagram:

